







The “**Export Position Data**” will allow you to export your unit/units into a CSV file format that can be imported into another mapping program on your laptop or PC.

The “**Administer Account**” button will allow you to set up a new password, set up your alarm notify and position report notify as well as check or uncheck what you want to see on the reports such as speed and heading.

The “**Add New User**” button allows you to set up 5 accounts that will allow your Friends and Family to log on and see your travels; this is not for the general public use.

The “**Account Status**” button allows you to see your account information such as billing and extra positions that you acquire during the month. It is a basic invoice for the account holder.

The “**Create a Public URL**” You may create a public URL that can be posted in various forums, on other WEB pages, or sent to friend or family member via e-mail. This will allow others to see the most recent position information. If the URL receives 500 or more views in a month then you will be credited a free month of subscription service (first 30 position reports) to Star-Traxx! So share the URL and earn a free month!

The “**Poll Remote Unit**” button performing a demand poll to a remote unit requires that a transmission be made from the satellite to the remote unit. This incurred a special charge on the satellite which will be included on your monthly bill. The charge for the demand poll is \$0.25.

The demand poll requires as much as 5 minutes to be performed. The remote unit may take several more minutes before it responds. You should not expect an update for up to 10 minutes. If the remote unit is not powered on or in a position where it has a clear view of the sky, it may not respond at all. You will still be charged for the satellite transmission to the remote unit.

The “**Page Remote Unit**” will allow you to send a special message to units equipped with the "Notification" script in the remote Star-Traxx unit. This will cause the LED on the Push-Button option to start blinking. This is only useful if you have pre-arranged with the user what action is to take place when they see the blinking LED. Typically this would be used as a "page" to ask that the Star-Traxx user call home.

When the Star-Traxx unit receives this special page, it will in turn transmit a position acknowledgment that will be relayed to the e-mail address used for alarm notification.

Performing a page notification to a remote unit requires that a transmission be made from the satellite to the remote unit. This incurred a special charge on the satellite which will be included on your monthly bill.  
The charge for the demand poll is \$0.25.

The “**Map Display**” displays the current map position and allows you to zoom in or out of that current map. We have over 35 maps to choose from including satellite maps and topo maps. Looking at the top of the map display you will see 2 options “print” or “email” the print option just lets you print that map out on your printer and the email option allows you to email this map and position report to anyone you choose. Also a new legend will appear based upon the map display that is currently shown.

Any questions email us or call  
[duane@star-traxx.com](mailto:duane@star-traxx.com)  
or  
[sales@neartime.com](mailto:sales@neartime.com)

Toll Free line 1-888-737-9817